

How to Recognise and Handle a Broken Garage Door Spring Safely - B&D; Australia - B&D; Australia

Canonical: <https://www.bnd.com.au/explore/resource-hub/our-blog/broken-garage-door-spring-safety/>

Details:

How to Recognise and Handle a Broken Garage Door Spring Safely - B&D; Australia - B&D; Australia
Menu Dealers Near Me Book Repair & Service Book Repair & Service Garage Door Visualiser Garage Door Visualiser Dealers Near Me Dealers Near Me Call Us 13 62 63 Call Us 13 62 63 Get A FREE Quote Get A FREE Quote Garage Doors and Openers Garage Doors and Openers Back Garage Doors and Openers Residential Doors Back Residential Doors View all residential doors Roller Doors Sectional Doors Designer Finishes Commercial Doors Back Commercial Doors View all commercial doors Commercial Roller Doors Commercial Sectional Doors Commercial Shutters Openers and Remotes Back Openers and Remotes View all openers and remotes Roller door openers Sectional door openers Garage remote controls Security & Smart Solutions Back Security & Smart Solutions View all safety & security solutions Smart door solutions Auto-Lock Safety Beams Explore Explore Back Explore Garage Door Visualiser Help me choose a garage door Explore range Explore designs and colours Inspiration Gallery Our Reviews Resource hub Back Resource hub View all resources Our Blog Videos Price Guide Case Studies Support Support Back Support Book Repair Back Book Repair Emergency Book Service Garage Door Warranty Door repair and maintenance Resources for owners Back Resources for owners Owner Manuals How-To Guide FAQ's Contact us Contact us Back Contact us Book Repair & Service Get A FREE Quote Dealers Near Me About Us Search Search Home Explore Resource hub Our Blog Broken Garage Door Spring Safety How to Recognise and Handle a Broken Garage Door Spring Safely A broken garage door spring can bring your day to a grinding halt. Whether you're heading to work or arriving home with groceries, a door that won't budge is inconvenient and can be dangerous if not handled properly. Knowing how to recognise the signs early and handle the situation safely can help you avoid costly repairs or personal injury. Let's break down what to watch for and what steps to take if your garage door spring fails. What Causes a Garage Door Spring To Break? Springs are the heavy lifters of your garage door. They bear the load every time the door opens or closes, making them one of the most hardworking components in the system. Over time, it's natural for them to wear down. Several factors can contribute to a broken garage door spring: Normal wear and tear – Most springs are rated for around 10,000 cycles. That's only a few years of daily use. Rust or corrosion – Moisture exposure can weaken the steel. Temperature swings – Extreme cold or heat can put added strain on the metal. Lack of professional servicing – Springs need periodic inspection and preventative maintenance, especially if your door sees regular use. Key Signs Your Garage Door Spring Is Broken It's not always obvious when a spring breaks, but there are some telltale signs. Recognising these early can help prevent further damage or injury. 1. A Loud Bang From the Garage Springs store a lot of tension. When one snaps, it often releases with a sharp, echoing sound, something many homeowners describe as similar to a firecracker or gunshot. 2. The Door Feels Extremely Heavy If the door suddenly feels much heavier than usual or can't be lifted manually, that's a clear indicator. Without a functioning spring, the opener has to bear all the weight, which it's not designed to do. 3. The Opener Starts but the Door Doesn't Move If your garage door opener hums or strains but doesn't lift the door, the spring may be the issue. You might also see the door rise a few centimetres before reversing. 4. Gaps or Distortion in the Spring Itself Visually inspect the spring. If you see a clean break, a stretched-out section, or the coils appear loose and uneven, that's a broken garage door spring. 5. The Door Lifts Unevenly or Jerks When one spring fails (on a double-spring setup), the door may open crookedly or look tilted as it lifts. What To Do if Your Spring Is Broken Stop

using the opener immediately Continuing to operate the door could strain other components, such as the motor, cables, or tracks. It also increases the risk of the door slamming shut. Don't try to fix it yourself Handling a broken garage door spring is dangerous without the right tools and training. The tension in the coils can cause serious injury if released improperly. Instead, book a professional garage door service through your local B&D; accredited dealer. Our technicians are trained to handle spring replacements safely and ensure the rest of your system is functioning correctly. Avoid forcing the door open Trying to manually lift the door without the spring's assistance could lead to muscle strain or finger injuries. If your vehicle is trapped inside, consider alternative transport arrangements until help arrives. How B&D; Helps Keep Your Door Safe and Reliable At B&D;, safety is engineered into every product. Our sectional and roller doors are designed with features that reduce strain on your system and minimise the chances of spring failure. We also recommend regular servicing to prevent problems before they start. Book an regular check-up through your local dealer to have your springs, tracks, and opener inspected and adjusted where needed. Frequently Asked Questions Can I replace a broken garage door spring myself? No. Garage door spring replacement is not a DIY task. The tension involved makes it dangerous. Always leave it to a qualified technician. How long do garage door springs typically last? Most standard springs last around 10,000 cycles. With daily use, that's about 5–7 years. Regular servicing can extend their lifespan. If you suspect a broken garage door spring, don't risk it. B&D;'s accredited dealer network is here to help. Book a professional service today and get your door running safely again. Contact us 13 62 63 13 62 63 Mon - Fri 8am-6pm AEST Head Office: 6-8 Fiveways Boulevard, Keysborough VIC 3173 Quick links Trade Resources Trade Resources Residential Garage Doors Residential Garage Doors Roller Doors Roller Doors Sectional Doors Sectional Doors Designer Finishes Designer Finishes Commercial Doors Commercial Doors Openers and Remotes Openers and Remotes Safety & Security Upgrades Safety & Security Upgrades Garage Door AUTO LOCK [™] Garage Door AUTO LOCK [™] Need Help? Get A FREE Quote Get A FREE Quote Price Guide Price Guide Garage Door Repair Garage Door Repair Garage Door Service Garage Door Service Find a Dealer Near Me Find a Dealer Near Me Garage Doors Blog Garage Doors Blog How-To Guide How-To Guide Product Manuals Product Manuals Garage Door Visualiser Garage Door Visualiser Frequently Asked Questions Frequently Asked Questions Australian Cybersecurity Act Statement of Compliance Australian Cybersecurity Act Statement of Compliance Product Support and Security Update Periods Product Support and Security Update Periods Repairs & Service Melbourne Garage Door Repairs Melbourne Garage Door Repairs Sydney Garage Door Repairs Sydney Garage Door Repairs Brisbane Garage Door Repairs Brisbane Garage Door Repairs Gold Coast Garage Door Repairs Gold Coast Garage Door Repairs Perth Garage Door Repairs Perth Garage Door Repairs Adelaide Garage Door Repairs Adelaide Garage Door Repairs Canberra Garage Door Repairs Canberra Garage Door Repairs Hobart Garage Door Repairs Hobart Garage Door Repairs Our Locations Melbourne Melbourne Sydney Sydney Brisbane Brisbane Gold Coast Gold Coast Adelaide Adelaide Perth Perth Canberra Canberra Hobart Hobart © 2026 B&D; Doors & Openers A division of B&D; Australia Pty Ltd. ABN 25 010 473 971. All rights reserved. About Us Privacy Policy Privacy Collection Statement User Terms Condition of Sale Careers Sitemap 13 62 63 Get A FREE Quote