

How to manually open a B&D; sectional garage door - B&D; Australia

Canonical: <https://www.bnd.com.au/support/resources-for-owners/how-to-guide/how-to-manually-open-a-bd-sectional-garage-door/>

Details:

How to manually open a B&D; sectional garage door - B&D; Australia Menu Dealers Near Me Book Repair & Service Book Repair & Service Garage Door Visualiser Garage Door Visualiser Dealers Near Me Dealers Near Me Call Us 13 62 63 Call Us 13 62 63 Get A FREE Quote Get A FREE Quote Garage Doors and Openers Garage Doors and Openers Back Garage Doors and Openers Residential Doors Back Residential Doors View all residential doors Roller Doors Sectional Doors Designer Finishes Commercial Doors Back Commercial Doors View all commercial doors Commercial Roller Doors Commercial Sectional Doors Commercial Shutters Openers and Remotes Back Openers and Remotes View all openers and remotes Roller door openers Sectional door openers Garage remote controls Security & Smart Solutions Back Security & Smart Solutions View all safety & security solutions Smart door solutions Auto-Lock Safety Beams Explore Explore Back Explore Garage Door Visualiser Help me choose a garage door Explore range Explore designs and colours Inspiration Gallery Our Reviews Resource hub Back Resource hub View all resources Our Blog Videos Price Guide Case Studies Support Support Back Support Book Repair Back Book Repair Emergency Book Service Garage Door Warranty Door repair and maintenance Resources for owners Back Resources for owners Owner Manuals How-To Guide FAQ's Contact us Contact us Back Contact us Book Repair & Service Get A FREE Quote Dealers Near Me About Us Search Search Home Support Resources for owners How-To Guide How to manually open a B&D; sectional garage door. How to manually open a B&D; sectional garage door How to manually open a B&D; sectional garage door. This is a quick video to show you how to manually operate your B&D; sectional garage door when your opener isn't working or your home is experiencing a power outage. Pull the manual release cord down until you hear a click. Your door is now released from the opener. Manually lift the door, taking extra care if the door is open or ajar. To manually secure the door, carefully close the garage door. Once the door is closed, re-engage the opener by pulling the manual release cord away from the door until you hear a click. You will see that the pin has clicked back into the horizontal position. The door is now secure. The garage door opener is now re-engaged. Use your remote, wall button or smart phone to test and make sure it lifts and lowers correctly. If you have completed all of these steps and your garage door is still not operating correctly your door may require a professional service , please call 13 62 63 . Play Garage door repair & servicing should only be provided by a trained professional Whether you've got a B&D; garage door or not, it's worth giving us a call every year or so. Our team of professional garage door technicians can service and repair all makes and models, and will keep your garage door in perfect working order, maintain its warranty and prevent potentially dangerous or expensive problems in the future. Call us or fill in the form below and we'll connect you with a B&D; dealer in your local area. Book Repair & Service Book Repair & Service Book Repair & Service Need help finding something? We have a number of ways to help you find what you're looking for. If in doubt, give our friendly team a call. We'd love to hear from you. FAQ's FAQ's FAQ's Call us Call us Call us Fill in a contact form Fill in a contact form Fill in a contact form Contact us 13 62 63 13 62 63 Mon - Fri 8am-6pm AEST Head Office: 6-8 Fiveways Boulevard, Keysborough VIC 3173 Quick links Trade Resources Trade Resources Residential Garage Doors Residential Garage Doors Roller Doors Roller Doors Sectional Doors Sectional Doors Designer Finishes Designer Finishes Commercial Doors Commercial Doors Openers and Remotes Openers and Remotes Safety & Security Upgrades Safety & Security Upgrades Garage Door AUTO LOCK ™ Garage Door AUTO LOCK ™ Need Help? Get A FREE Quote Get A FREE Quote Price

[Guide Price Guide](#) [Garage Door Repair](#) [Garage Door Repair](#) [Garage Door Service](#) [Garage Door Service](#) [Find a Dealer Near Me](#) [Find a Dealer Near Me](#) [Garage Doors Blog](#) [Garage Doors Blog](#) [How-To Guide](#) [How-To Guide](#) [Product Manuals](#) [Product Manuals](#) [Garage Door Visualiser](#) [Garage Door Visualiser](#) [Frequently Asked Questions](#) [Frequently Asked Questions](#) [Australian Cybersecurity Act](#) [Statement of Compliance](#) [Australian Cybersecurity Act](#) [Statement of Compliance](#) [Product Support and Security Update Periods](#) [Product Support and Security Update Periods](#) [Repairs & Service Melbourne](#) [Garage Door Repairs Melbourne](#) [Garage Door Repairs Sydney](#) [Garage Door Repairs Sydney](#) [Garage Door Repairs Brisbane](#) [Garage Door Repairs Brisbane](#) [Garage Door Repairs Gold Coast](#) [Garage Door Repairs Gold Coast](#) [Garage Door Repairs Perth](#) [Garage Door Repairs Perth](#) [Garage Door Repairs Adelaide](#) [Garage Door Repairs Adelaide](#) [Garage Door Repairs Canberra](#) [Garage Door Repairs Canberra](#) [Garage Door Repairs Hobart](#) [Garage Door Repairs Hobart](#) [Garage Door Repairs Our Locations](#) [Melbourne Melbourne](#) [Sydney Sydney](#) [Brisbane Brisbane](#) [Gold Coast Gold Coast](#) [Adelaide Adelaide](#) [Perth Perth](#) [Canberra Canberra](#) [Hobart Hobart](#) © 2026 B&D; Doors & Openers A division of B&D; Australia Pty Ltd. ABN 25 010 473 971. All rights reserved. [About Us](#) [Privacy Policy](#) [Privacy Collection Statement](#) [User Terms](#) [Condition of Sale](#) [Careers](#) [Sitemap](#) [13 62 63](#) [Get A FREE Quote](#)